



Liquid Biopsy Research - "We are where you start"

# HighPrep™ Total RNA Plus Kit

Manual Revision v2.00

Catalog Nos. HPTOR-R5, HPTOR-R50, HPTOR-R100, HPTOR-R400

- RNA isolation from tissues, cultured cells, and whole blood
- Magnetic beads based chemistry

## Contents

Product Description and Process.....	1
Kit Contents, Storage, Stability.....	1
Preparation of Reagents .....	2
HighPrep™ Total RNA Plus - Tissue & Cultured Cells Protocol .....	3
HighPrep™ Total RNA Plus - Whole Blood Protocol.....	6
Troubleshooting Guide .....	9

### For Research Use Only. Not for use in diagnostic procedures.

Information in this document is subject to change without notice.

MAGBIO GENOMICS, INC. DISCLAIMS ALL WARRANTIES WITH RESPECT TO THIS DOCUMENT, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THOSE OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TO THE FULLEST EXTENT ALLOWED BY LAW, IN NO EVENT SHALL MAGBIO GENOMICS, INC. BE LIABLE, WHETHER IN CONTRACT, TORT, WARRANTY, OR UNDER ANY STATUTE OR ON ANY OTHER BASIS FOR SPECIAL, INCIDENTAL, INDIRECT, PUNITIVE, MULTIPLE OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH OR ARISING FROM THIS DOCUMENT, INCLUDING BUT NOT LIMITED TO THE USE THEREOF, WHETHER OR NOT FORESEEABLE AND WHETHER OR NOT MAGBIO GENOMICS, INC. IS ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

### TRADEMARKS

The trademarks mentioned herein are the property of Magbio Genomics, Inc. or their respective owners.



Australian distributors:  
Fisher Biotec Australia  
free call: 1800 066 077  
email: [info@fisherbiotec.com](mailto:info@fisherbiotec.com)  
web: [www.fisherbiotec.com](http://www.fisherbiotec.com)

## Product Description

The HighPrep™ Total RNA Plus Kit is specially designed for purifying total RNA from a wide variety of tissues, cultured cells, and whole blood. The kit uses the special lysis condition with HighPrep™ magnetic particles technology to isolate high-quality total RNA from 5-30 mg of tissue, 200 µl of whole blood, or 1 x 10<sup>6</sup> of cultured cells. Purified RNA is suitable for all major downstream applications such as RNA-Seq, RT-PCR, NGS, and hybridization applications.

## Process

The HighPrep™ Total RNA Plus kit uses a simple 4 steps procedure: Lyse+Bind-Wash-Elute. Tissue, blood, or cells are lysed, and released DNA and RNA binds to the HighPrep™ MAG-D4 magnetic beads in one step. Utilizing a magnetic separation device, the bound genomic DNA and RNA are separated from the solution and washed. Genomic DNA is removed with a DNase Digestion step. After 2 wash steps, RNA is eluted from magnetic beads.

## Kit Contents and Storage

HighPrep™ Total RNA Plus Kit Catalog No.	HPTOR-R5	HPTOR-R50	HPTOR-R100	HPTOR-R400	STORAGE
Number of Preps	5	50	100	400	
Solution A	5 mL	50 mL	100 mL	400 mL	15-25°C
RLB Buffer	2.8 mL	28 mL	56 mL	224 mL	15-25°C
DCE Buffer <sup>1</sup>	0.8 mL	8 mL	16 mL	64 mL	15-25°C
MRW1 Buffer <sup>1</sup>	2 mL	20 mL	40 mL	160 mL	15-25°C
RWB2 Buffer <sup>1</sup>	2 mL	20 mL	40 mL	160 mL	15-25°C
Pro K Solution	0.11 mL	1.1 mL	2.2 mL	8.8 mL	2-8°C
DNase I	0.011 ml	0.110 mL	0.22 mL	.88 mL	-20°C
DNase I Digestion Buffer	0.6 mL	6 mL	12 mL	48 mL	15-25°C
RNA Elution Buffer	1 mL	10 mL	16 mL	64 mL	15-25°C
MAG-D4 Particles	0.055 mL	0.55 mL	1.1 mL	4.4 mL	2-8°C

<sup>1</sup> Ethanol must be added prior to use. See Preparation of Reagents

## Stability

All components are stable for 14 months when stored accordingly.

## Safety Information

When working with chemicals, always wear a suitable lab coat, disposable gloves, and protective goggles. For more information, please consult the appropriate material safety data sheets (MSDSs). MSDS can be downloaded from the "Product Resource" tab when viewing the product kit.

## Preparation of Reagents

Prepare the following components for each kit before use:

Catalog No.	Component	Add 100% Ethanol	Storage
HPTOR-R5	DCE Buffer	2 mL	Room Temp 15-25°C
	MRW1 Buffer	1.25 mL	Room Temp 15-25°C
	RWB2 Buffer	8 mL	Room Temp 15-25°C
Components are stable for 1 year when stored closed at room temperature			

Catalog No.	Component	Add 100% Ethanol	Storage
HPTOR-R50	DCE Buffer	20 mL	Room Temp 15-25°C
	MRW1 Buffer	12.5 mL	Room Temp 15-25°C
	RWB2 Buffer	80 mL	Room Temp 15-25°C
Components are stable for 1 year when stored closed at room temperature			

Catalog No.	Component	Add 100% Ethanol	Storage
HPTOR-R100	DCE Buffer	40 mL	Room Temp 15-25°C
	MRW1 Buffer	25 mL	Room Temp 15-25°C
	RWB2 Buffer	160 mL	Room Temp 15-25°C
Components are stable for 1 year when stored closed at room temperature			

Catalog No.	Component	Add 100% Ethanol	Storage
HPTOR-R400	DCE Buffer	160 mL	Room Temp 15-25°C
	MRW1 Buffer	100 mL	Room Temp 15-25°C
	RWB2 Buffer	640 mL	Room Temp 15-25°C
Magbio Genomics, Inc.			

## HighPrep™ Total RNA Plus - Tissue & Cultured Cells Protocol

### Equipment and Reagents to Be Supplied by User

When working with chemicals, always wear a suitable lab coat, disposable gloves, and protective goggles. For more information, please consult the appropriate material safety data sheets (MSDSs) from each product supplier.

- Nuclease-free 1.5 ml microcentrifuge tubes
- Magnetic separation device
- Equipment for disrupting and homogenizing tissue
- 100% Ethanol
- Water bath, incubator, or heat block capable of 65°C

### Things to do before starting

- Ensure the work area is RNase free
- Prepare reagents according to Preparation of Reagents Section
- Preset water bath, incubator or heating blocks to 65°C
- Completely resuspend the MAG-D4 Particles by vortexing


### Protocol - 1.5 ml tube format

1. **Homogenize the tissue or cells samples using an appropriate method. See below for examples of common homogenization methods:**

- **For tissue samples**

**1) Mortar and Pestle:** Collect ~30mg fresh or preserved tissue sample in a mortar and freeze in liquid nitrogen. Grind the tissue using a clean pestle. Transfer the ground powder and liquid nitrogen into a 1.5 mL tube and allow the liquid nitrogen to evaporate. Add 500 µl of RLB Buffer and vortex immediately and thoroughly.


**2) Bead-beating:** Grind the ~30mg tissue in 500 µl of RLB Buffer in a commercial bead-beater. Parameters such as grinding speed, duration, temperature, and type of beads, and etc. may need to be optimized. Refer to the manufacturer's manual for additional instructions.

 *Note: Pro K Solution is not necessary when using a clean mortar or bead-beating to grind tissue samples.*


- **For cultured cells**

**Resuspend the  $1 \times 10^6$  cultured cell pellet in 500 µl of RLB Buffer by vortexing or pipetting up-and-down thoroughly. Add 20 µl of Pro K, mix immediately by vortexing for 20 seconds, and incubate the sample at room temperature for 5 min. Vortex briefly once during incubation. If desired, using a rotor-stator homogenizer or passing through a 20-gauge needle may increase the yield.**

- 2. Centrifuge the sample at 10,000 x g for 10 minutes at 4°C. Transfer 400 µl of the clear lysate to a new tube. Do not disturb the debris pellet.**


 *Note: If the clear lysate is less than 400 µl, bring the volume up to 400 µl with RLB Buffer or add the same volume of diluted DCE Buffer at step 3.*

- 3. Add 400 µl of DCE buffer and 10 µl of MAG-D4 Particles to each sample, vortex to mix thoroughly and incubate at room temperature for 10 minutes.**

 *Note: DCE Buffer must be diluted with ethanol prior to use. Complete resuspension of the magnetic particles is critical for obtaining high quality RNA.*


- 4. Place the sample tubes on the magnetic separation device to magnetize the MAG-D4 Particles for 2-5 minutes, or until the magnetic particles are completely cleared from the solution. Remove and discard the cleared supernatant. Do not disturb the magnetic particles.**

- 5. Add 600 µl of MRW1 Buffer to the sample and re-suspend the magnetic particles by vortexing at maximum speed for 1 min or by pipetting up and down 10 times.**


 *Note: MRW1 Buffer must be diluted with ethanol prior to use. Complete resuspension of the magnetic particles is critical for obtaining high quality RNA.*

- 6. Place the sample tubes on the magnetic separation device to magnetize the MAG-D4 Particles for 2-5 minutes, or until the magnetic particles are completely cleared from the solution. Remove and discard the cleared supernatant. Do not disturb the magnetic particles.**

- 7. Add 600 µl of RWB2 buffer to the sample and re-suspend the magnetic particles by vortexing at maximum speed for 1 min or by pipetting up and down 10 times.**

 *Note: Complete resuspension of the magnetic particles is critical for obtaining high quality RNA. RWB2 Buffer must be diluted with ethanol before use.*

- 8. Place the sample tubes on the magnetic separation device to magnetize the MAG-D4 Particles for 2-5 minutes, or until the magnetic particles are completely cleared from solution. Remove and discard the cleared supernatant. Do not disturb the magnetic particles.**

 *Note: All liquid must be aspirated at this step. It is helpful to remove all liquid from the well then wait for one minute and remove any residual liquid from the well using a fine pipet tip.*


- 9. Leave the tubes on the magnetic separation device for 5 minutes to air dry the MAG-D4 Particles.**

- 10. While the samples are drying, prepare the DNase I mixture. For each sample, gently mix 98 µl of DNase I digestion buffer and 2 µl of DNase I.**

- 11. Add 100 µl of the DNase I mixture to each sample. Gently mix by pipetting up and down to fully resuspend the magnetic beads. Incubate the samples at room temperature for 10 minutes.**

 *Note: Avoid extensive vortexing or pipetting as this may denature the DNase I.*

- 12. Add 600 µl of RWB2 Buffer to the sample and resuspend the magnetic particles by vortexing at maximum speed for 1 min or by pipetting up and down 10 times. Incubate the samples at room temperature for 1 minute.**

 *Note: RWB2 Buffer must be diluted with ethanol before use.*

- 13. Place the sample tubes on the magnetic separation device to magnetize the MAG-D4 Particles for 2-5 minutes, or until the magnetic particles are completely cleared from the solution. Remove and discard the cleared supernatant. Do not disturb the magnetic particles.**


- 14. Repeat Steps 12-13 for a second RNA wash.**

- 15. Leave the tubes on the magnetic separation device for 5-10 minutes to air dry the MAG-D4 Particles. Remove any residual liquid with a fine pipet tip.**

 *Note: it is critical to completely remove all liquid from each tube.*

- 16. Add 50-100 µl of RNA Elution Buffer. Completely resuspend the MAG-D4 Particles by vortexing at maximum speed for 1 min or by pipetting up and down 10 times.**

- 17. Incubate for 10 minutes at room temperature.**

 *Note: Incubation at 65°C may improve the yield for some tissue samples, but it may decrease the sample's RNA integrity number (RIN) values.*

- 18. Place the tubes back on the magnetic separation device and wait 2-5 minutes or until the magnetic particles are completely cleared from the Elution Buffer.**

- 19. Transfer the cleared supernatant containing the purified RNA to a new 1.5 mL tube.**

- 20. Store the RNA at -80°C.**

## HighPrep™ Total RNA Plus - Whole Blood Protocol

### Equipment and Reagents to Be Supplied by User

When working with chemicals, always wear a suitable lab coat, disposable gloves, and protective goggles. For more information, please consult the appropriate material safety data sheets (MSDSs) from each product supplier.


- Nuclease-free 1.5 ml microcentrifuge tubes
- Magnetic separation device
- 100% Ethanol
- Water bath, incubator, or heat block capable of 65°C

### Things to do before starting


- Ensure the work area is RNase free
- Prepare reagents according to Preparation of Reagents Section
- Preset water bath, incubator or heating blocks to 65°C
- Completely resuspend the MAG-D4 Particles by vortexing

### Protocol - 1.5 ml tube format


1. **Add 200 µl of whole blood in a 1.5 ml microcentrifuge tube and 600 µl of Solution A.**
2. **Mix well and centrifuge at 10,000 x g for 5 min at 4°C. Decant the supernatant and keep the pellet.**
3. **Add 200 µl of Solution A and mix gently to break the pellet.**
4. **Centrifuge the sample at 10,000 x g for 5 min at 4°C for the final wash. Decant the supernatant and keep the pellet.**
5. **Add 500 µl of RLB Buffer to the pellet and 20 µl of Pro K, incubate the sample at room temperature for 20 min. Vortex briefly once during incubation.**
6. **Centrifuge the sample at 10,000 x g for 10 minutes at 4°C. Transfer 400 µl of the clear lysate to a new tube. Do not disturb the debris pellet.**

 *Note: If the clear lysate is less than 400 µl, bring the volume up to 400 µl with RLB Buffer or add the same volume of diluted DCE Buffer at step 3.*


7. **Add 400 µl of DCE buffer and 10 µl of MAG-D4 Particles to each sample. Vortex to mix thoroughly and incubate at room temperature for 10 minutes.**

 *Note: DCE Buffer must be diluted with ethanol prior to use. Complete resuspension of the magnetic particles is critical for obtaining high quality RNA.*


8. **Place the sample tubes on the magnetic separation device to magnetize the MAG-D4 Particles for 2-5 minutes, or until the magnetic particles are completely cleared from solution. Remove and discard the cleared supernatant. Do not disturb the magnetic particles.**
9. **Add 600 µl of MRW1 Buffer to the sample and re-suspend the magnetic particles by vortexing at maximum speed for 1 min or by pipetting up and down 10 times.**

 *Note: MRW1 Buffer must be diluted with ethanol prior to use. Complete resuspension of the magnetic particles is critical for obtaining high quality RNA.*

10. **Place the sample tubes on the magnetic separation device to magnetize the MAG-D4 Particles for 2-5 minutes, or until the magnetic particles are completely cleared from the solution. Remove and discard the cleared supernatant. Do not disturb the magnetic particles.**
11. **Add 600 µl of RWB2 buffer to the sample and re-suspend the magnetic particles by vortexing at maximum speed for 1 min or by pipetting up and down 10 times.**

 *Note: Complete resuspension of the magnetic particles is critical for obtaining high quality RNA. RWB2 Buffer must be diluted with ethanol before use.*

12. **Place the sample tubes on the magnetic separation device to magnetize the MAG-D4 Particles for 2-5 minutes, or until the magnetic particles are completely cleared from solution. Remove and discard the cleared supernatant. Do not disturb the magnetic particles.**

 *Note: All liquid must be aspirated at this step. It is helpful to remove all liquid from the well then wait for one minute and remove any residual liquid from the well using a fine pipet tip.*

13. **Leave the tubes on the magnetic separation device for 5 minutes to air dry the MAG-D4 Particles.**
14. **While the samples are drying, prepare the DNase I mixture. For each sample, gently Mix 98 µl of DNase I digestion buffer and 2 µl of DNase I.**

 *Note: Avoid extensive vortexing or pipetting as this may denature the DNase I.*

15. **Add 100 µl of DNase I mixture to each sample. Gently mix by pipetting up and down to fully resuspend the magnetic beads. Incubate the samples at room temperature for 10 minutes.**
16. **Add 600 µl of RWB2 Buffer to the sample and resuspend the magnetic particles by vortexing at maximum speed for 1 min or by pipetting up and down 10 times. Incubate the samples at room temperature for 1 minute.**

 *Note: RWB2 Buffer must be diluted with ethanol before use.*


17. **Place the sample tubes on the magnetic separation device to magnetize the MAG-D4 Particles for 2-5 minutes, or until the magnetic particles are completely cleared from the solution. Remove and discard the cleared supernatant. Do not disturb the magnetic particles.**



- 18. Repeat Steps 12-13 for a second RNA wash.**
- 19. Leave the tubes on the magnetic separation device for 5-10 minutes to air dry the MAG-D4 Particles. Remove any residual liquid with a fine pipet tip.**

 *Note: it is critical to completely remove all liquid from each tube.*

- 20. Add 50-100 µl of RNA Elution Buffer. Completely resuspend the MAG-D4 Particles by vortexing at maximum speed for 1 min or by pipetting up and down 10 times.**
- 21. Incubate for 10 minutes at room temperature.**

 *Note: Incubation at 65°C may improve the yield for some tissue samples, but it may decrease the sample's RNA integrity number (RIN) values.*

- 22. Place the tubes back on the magnetic separation device and wait 2-5 minutes or until the magnetic particles are completely cleared from the Elution Buffer.**
- 23. Transfer the cleared supernatant containing the purified RNA to a new 1.5 mL tube.**
- 24. Store the RNA at -80°C.**

## Troubleshooting guide

Please use this guide to troubleshoot any problems that may arise. For further assistance, please contact technical support via:

Phone: 1-855-262-4246 (in US), outside US, 1-919-719-0665

Email: support@magbiogenomics.com

Symptoms	Possible Causes	Comments
Low RNA yield	Incomplete resuspension of HighPrep™ MAG-D4 particles	Resuspend the HighPrep™ MAG-D4 particles by vortexing before use.
	RNA degraded during storage	Make sure the sample is properly stored and make sure the samples are processed immediately after collection or removal from storage.
	Low levels of leukocytes	Low white blood cell count will give reduced yield.
	Loss of HighPrep™ MAG-D4 particles during procedure	Be careful not to remove the HighPrep™ MAG-D4 particles during the procedure.
	Ethanol was not added to Wash Buffers	Add ethanol to Wash Buffers as instructed on Page 4.
	HighPrep™ MAG-D4 particles not resuspended during binding	Vortex vigorously for 2 minutes after addition of ethanol and HighPrep™ MAG-D4 particles.
Problem with downstream application	Insufficient RNA was used	RNA in the sample already degraded. Do not freeze/thaw the sample more than once. Do not store at room temperature.
	Ethanol carry-over	Dry the HighPrep™ MAG-D4 Particles completely before elution.
Carryover of the magnetic particles in the elution	Carryover of the HighPrep™ MAG-D4 particles in the eluted RNA will not affect downstream applications	To remove the carryover HighPrep™ MAG-D4 particles from the eluted RNA, simply place the plate on the magnetic separation device and wait until the eluate has cleared. Carefully transfer the RNA eluate to a new 96-well plate.

## Ordering Information

Product Description	Catalog No.	Preps
HighPrep™ Total RNA Plus kit - 50 preps	HPTOR-R50	50
HighPrep™ Total RNA Plus kit - 100 preps	HPTOR-R100	100
HighPrep™ Total RNA Plus kit - 400 preps	HPTOR-R400	400

## Precautions and Disclaimers

This kit is designed for research purposes only. It is not intended for human or diagnostic use. All biological samples are considered potentially infectious. When working with the samples and chemicals always wear a suitable lab coat, disposable gloves, and protective goggles. For more information please consult the appropriate Material Safety Data Sheets (MSDSs).



Liquid Biopsy Research - "We are where you start"



Australian distributors:  
Fisher Biotec Australia  
free call: 1800 066 077  
email: [info@fisherbiotec.com](mailto:info@fisherbiotec.com)  
web: [www.fisherbiotec.com](http://www.fisherbiotec.com)

The complex block contains the Fisher Biotec Australia logo on the left, which includes the lowercase letters "fB" in white on an orange square, with "fisher biotec australia" written below it. To the right of the logo is a circular badge with "20 YEARS" in the center, "MORE THAN" above, and "IN BUSINESS" below. At the bottom of the badge, it says "Established 1997". To the right of the badge is a vertical orange line.